



FRONT VIEW

SIDE VIEW - WALL MOUNT

NOTES:

1. VARIABLE FREQUENCY DRIVE (VFD) IS PROVIDED AND INSTALLED BY CONTRACTOR.
2. KEEP ALL LOW VOLTAGE CONTROL WIRING (UNDER 25V) AND HIGH VOLTAGE POWER WIRING (OVER 25V) SEPARATED. (RUN IN SEPARATE CONDUIT).
3. PLYWOOD SIZE IS BASED ON ONE VFD IN EACH LOCATION. FOR MULTIPLE VFD'S, COORDINATE WITH OWNER'S REPRESENTATIVE.
4. POWER TO DRIVE AND LEADS TO MOTOR MUST BE IN SEPARATE CONDUIT.
5. INSTALL ISO TRANSFORMER IF REQUIRED.
6. DO NOT PLACE ISO TRANSFORMER BELOW VFD.
7. IF REMOTE SERVICE DISCONNECT IS REQUIRED IT MUST BE HARDWIRED TO VFD SAFTEY CIRCUIT TO SHUT DOWN DRIVE IF DISCONNECT IS OPENED.

E VFD MOUNTING DETAIL
NO SCALE