



- NOTES: 1. LOCATE JUNCTION BOXES AS FOLLOWS:  
 A. AT EVERY TEE IN THE CONDUIT.  
 B. AFTER 270 DEGREES OF BEND IN THE CONDUIT.

REV	DATE
0	12/18/02
1	2/9/2016
DRAWN BY: AM	
CHECKED BY: TG	

# Construction Standard CW Junction Box



Energy Management  
 Campus Facilities  
 UNIVERSITY OF MISSOURI-COLUMBIA



DRAWING  
 NOT TO SCALE  
 DATE: 2/9/2016